

Elmers
school glue on
edge of both
wings, then sprinkle
with medium 96 coe

**frit** (lightly press down on the glue to set frit and carefully dust off to the glued side and place in kiln)

## Kiln Program for 96 coe segments 2

- 1 ramp @ 300\* to 1350\* hold for 5 minutes
- 2 ramp to 950\* hold for 10 minutes end program

Kilns may vary so always do a test first. your frit should stick, but still retain a frost crystal like appearance

Don't have a kiln? just skip that part and use iridized white!

loop with small ribbon!



Glue wings and small bail to the body as shown and clip until dry. I like to use a two part 5 minute epoxy or clear silicone

